



Limora Zentrallager
Industriepark Nord 21
D - 53567 Buchholz
Tel: +49 (0) 26 83 - 97 99 0
E-Mail: Limora@Limora.com
Internet: www.Limora.com



Einbauanleitung für Alu Kraftstofftank 19261

Bitte beachten sie, dass die Ablassschraube und die beiden kleineren Verschraubungen für den Kraftstoffanschluss mit Schraubensicherung eingeklebt sind. Um diese zu lösen, müssen sie einen Heißluftfön oder ein Heißluftgebläse verwenden. Wenn alles erwärmt ist, lässt sich die Schraube problemlos entfernen.

Manchmal sind nach dem Lösen der Schraubensicherung noch trockene Reste an den Teilen. Auch diese können Sie mit Hilfe von Wärme einfach entfernen.

Achtung: Verwenden Sie niemals rohe Gewalt, um eine Schraubensicherung zu entfernen. Dies birgt die Gefahr, Gewinde oder gar den Kraftstofftank zu beschädigen.



Instructions for alloy fuel tank 19261

Please note that the drain plug and the two smaller screw plugs for the fuel pipe are glued in with retaining compound. To loosen this, you must use a hot air gun or a hot air blower. Once everything has warmed up, the screw plug can be removed easily.

Sometimes there are still dry residues on the parts after the retaining compound has been removed. These can also be easily removed with the help of heat.

Caution: Never use brute force to remove a retaining compound. There is a risk of damaging threads or even the fuel tank.

